

Installation Guide

• Supplement •

EdgeConnect

RACK MOUNT

INSTRUCTIONS

• EAR MOUNT •

EC-XS

Before You Begin

- ❑ Check your packing slip to verify that you have all the necessary items.
- ❑ Make sure you have a standard Phillips screwdriver.
- ❑ You can mount the chassis in either a 2-post telco rack or a 4-post server rack.
- ❑ If your rack requires its own screws and/or nuts, then use those instead.

The SD-WAN gateway fits into 1 RU of rack space.

The gateway ships with the following:

- Two (2) metal brackets and six (6) black screws to attach them to the gateway
- Four (4) M5 x 5/8" screws and four (4) cage nuts for mounting the gateway in a rack

To mount this gateway in consecutive spaces in a 1-U rack, you'll first need to remove the feet from the round indentations in the bottom of the gateway.

To mount the gateway into the telco or server rack:


1. Align the three holes in the gateway with the holes in the brackets.



2. Secure the bracket to the gateway with three screws.



3. In the same manner, attach the other bracket to the other side.



4. Attach the cage nuts to the rear of the front rack posts.
5. Use the screws to secure the chassis to the outside front of the rack.



Hewlett Packard Enterprise Company
Attn: General Counsel
WW Corporate Headquarters
1701 E Mossy Oaks Rd
Houston, TX 77389

1.800.943.4526 (toll-free in USA)
+1.650.750.0350

Support:
<https://networkingsupport.hpe.com/home>

